

## DISHWASHER PRODUCT FICHE

|                          |               |
|--------------------------|---------------|
| BRAND NAME               | WHIRLPOOL     |
| COMMERCIAL CODE          | WBC 3C34 PF X |
| NUMBER OF PLACE SETTINGS | 14            |
| ENERGY EFFICIENCY CLASS  | A+++          |

*Energy consumption 238 kWh per year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used.*

|                                             |           |
|---------------------------------------------|-----------|
| ENERGY CONSUMPTION OF THE "Eco 50°" PROGRAM | 0.833 kWh |
| POWER CONSUMPTION IN LEFT-ON MODE           | 6 W       |
| POWER CONSUMPTION IN OFF MODE               | 0,50 W    |

*Water consumption 2660 l per year, based on 280 standard cleaning cycles. Actual water consumption will depend on how the appliance is used.*

*Drying efficiency class A on a scale from G (least efficient) to A (most efficient).*

*The "Eco 50°" is the standard cleaning cycle to which the information in the label and the fiche relates. This program is suitable to clean normally soiled tableware, and it is the most efficient program in terms of combined energy and water consumption.*

|                                    |                 |
|------------------------------------|-----------------|
| CYCLE TIME FOR THE Eco 50° PROGRAM | 190 min         |
| DURATION OF LEFT-ON MODE           | 12 min          |
| NOISE LEVEL dB(A) re 1 pW          | 44              |
| TYPE OF INSTALLATION               | Half-integrated |